

Memory Stick® Media Compatibility Information for Alpha Cameras

Important Information:

- This "Compatibility Chart" only provides compatibility testing results for the Memory Stick media applications listed in each product's instruction manual with Memory Stick media types listed below.
- This chart does not guarantee support for all Memory Stick media types' performance nor compatibility among Memory Stick media compliant products.
- Memory Stick media transmission speed varies by, and depends on, host hardware devices' features and circumstances of use.
- The recording time and the number of still images that can be recorded will vary by device. Refer to the instruction manual supplied with your camera for more information.
- Attach a dedicated adapter to use Memory Stick Duo™ media in a slot for standard size media.
- The Memory Stick media capacity indicated on the packaging will differ from actual usable capacity. A portion of the memory is used for data management file functions. Refer to the back of the packaging for the minimum guaranteed capacity. [Click here to view the Memory Stick media user capacity chart.](#)
- This compatibility chart and specifications are subject to change without notice.

Notes:

2	The Transmission speed may not be faster when using Memory Stick PRO™ (High Speed/Mark2) and Memory Stick PRO-HG™.
4	A dedicated adapter must be attached to use the Memory Stick Micro™ media .
7	This Memory Stick™ may not be able to record or play video.
9	Use a Memory Stick™ 1GB or over when shooting video.
13	Use the AD-MSCF1 Memory Stick™ adaptor for Memory Stick Duo™ media.
18	The recording failure of sound may occur by pushing the DIVIDE button during recording.
20	The recording failure of sound may briefly occur while pre-recording buffer is activated.
37	This media is not compatible with HD movie mode.
39	TransferJet function is not available for use with this product.
41	This media cannot be used in "Standard mode" as file system is different.
42	This media cannot be used when Secure Access is set to ON. Please switch off Secure Access function, using the software Memory Media Utility.
43	Mirroring function is not available for use with this product.
44	This media is not compatible with simultaneous movie recording in Standard mode.
45	This media is not compatible with simultaneous movie recording.
53	This media is not compatible with XAVC S movie mode.

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

	Memory Stick													
Camera	MS-HX4G	MS-HX8A	MS-HX8AG	MS-HX8B	MS-HX8G	MS-JX8G	MS-M16	MS-M4	MS-M8	MS-MT16G	MS-MT1G	MS-MT2G	MS-MT32G	MS-MT4G
DSLR-A100	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13 *39	-	-	-	-	OK *13	OK *13	-	OK *13
DSLR-A100H	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13 *39	-	-	-	-	OK *13	OK *13	-	OK *13
DSLR-A100K	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13 *39	-	-	-	-	OK *13	OK *13	-	OK *13
DSLR-A100W	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13 *39	-	-	-	-	OK *13	OK *13	-	OK *13
DSLR-A200K	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13 *39	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A200W	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13 *39	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A230L	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A230Y	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A290L	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A300K	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13 *39	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A300X	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13 *39	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A330L	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A330Y	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A350	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A350K	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A350X	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A380L	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A380Y	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A390L	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A500	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A500L	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A550	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A550L	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK

	Memory Stick													
Camera	MS-HX4G	MS-HX8A	MS-HX8AG	MS-HX8B	MS-HX8G	MS-JX8G	MS-M16	MS-M4	MS-M8	MS-MT16G	MS-MT1G	MS-MT2G	MS-MT32G	MS-MT4G
DSLR-A560	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
DSLR-A560L	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
DSLR-A580	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
DSLR-A580L	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
DSLR-A700	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A700H	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A700K	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A700P	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A850	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
DSLR-A900	OK	OK	OK	OK	OK	OK *39	OK *4	OK *4	OK *4	OK	OK	OK	OK	OK
ILCA-77M2	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCA-77M2M	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCA-77M2Q	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-3000K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-3500J	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-5000L	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-5000Y	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-6000	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-6000L	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-6000Y	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-7	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-7R	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
ILCE-7S	OK *53	OK *53	OK *53	OK *53	OK *53	OK *39 *53	OK *4 *37 *53	OK *4 *37 *53	OK *4 *37 *53	OK *53	OK *53	OK *53	OK *53	OK *53

	Memory Stick													
Camera	MS-HX4G	MS-HX8A	MS-HX8AG	MS-HX8B	MS-HX8G	MS-JX8G	MS-M16	MS-M4	MS-M8	MS-MT16G	MS-MT1G	MS-MT2G	MS-MT32G	MS-MT4G
NEX-3A	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-3K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-3NL	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-5A	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-5K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-5N	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-5NK	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-5R	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-5RK	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-5RL	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-5T	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-5TL	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-6	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-6L	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-7	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-7K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-C3A	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-C3K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
NEX-F3K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A33	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A33L	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A35	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A35K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK

	Memory Stick													
Camera	MS-HX4G	MS-HX8A	MS-HX8AG	MS-HX8B	MS-HX8G	MS-JX8G	MS-M16	MS-M4	MS-M8	MS-MT16G	MS-MT1G	MS-MT2G	MS-MT32G	MS-MT4G
SLT-A35Y	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A37	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A37K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A37L	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A37M	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A55V	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A55VL	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A57	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A57K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A57M	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A58K	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A65V	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A65VK	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A65VL	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A65VM	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A77V	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A77VM	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A77VQ	OK	OK	OK	OK	OK	OK *39	OK *4 *37	OK *4 *37	OK *4 *37	OK	OK	OK	OK	OK
SLT-A99	OK	OK	OK	OK	OK	OK *39	OK *4 *37 *45	OK *4 *37 *45	OK *4 *37 *45	OK *45	OK *45	OK *45	OK *45	OK *45
SLT-A99V	OK	OK	OK	OK	OK	OK *39	OK *4 *37 *45	OK *4 *37 *45	OK *4 *37 *45	OK *45	OK *45	OK *45	OK *45	OK *45

	Memory Stick											
Camera	MS-MT8G	MS-PX16	MS-PX32	MS-PX64	MSX-M1GS	MSX-M1GST	MSX-M256	MSX-M256S	MSX-M2GS	MSX-M4GS	MSX-M512S	MSX-M8GS
DSLR-A100	OK *13	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A100H	OK *13	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A100K	OK *13	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A100W	OK *13	-	-	-	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A200K	OK *13	OK *13 *42	OK *13 *42	OK *13 *42	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A200W	OK *13	OK *13 *42	OK *13 *42	OK *13 *42	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A230L	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A230Y	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A290L	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A300K	OK *13	OK *13 *42	OK *13 *42	OK *13 *42	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A300X	OK *13	OK *13 *42	OK *13 *42	OK *13 *42	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A330L	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A330Y	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A350	OK *13	OK *13 *42	OK *13 *42	OK *13 *42	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A350K	OK *13	OK *13 *42	OK *13 *42	OK *13 *42	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A350X	OK *13	OK *13 *42	OK *13 *42	OK *13 *42	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13	OK *13
DSLR-A380L	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A380Y	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A390L	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A500	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A500L	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A550	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK
DSLR-A550L	OK	OK *42	OK *42	OK *41 *42	OK	OK	OK	OK	OK	OK	OK	OK

[illegible]

[illegible]

[illegible]